

<Hot Key>, <o> or <OSD Fast Key>	Open OSD.
(CPU selection), <Enter>	Set a KVM connection (keyboard, mouse and video) to the selected source (computer, CPU).
(CPU selection), <Space>	Set a Video Only connection to the selected source (computer, CPU).
(CPU selection), <Left Shift> + <Enter>	Set a Private Access connection to the selected source (computer, CPU).
<Hot Key>, <Backspace>	Close the current connection of the own console.
<Hot Key>, <p>	Switch back to the previous connected source (computer, CPU) with Full Access.

<Hot Key>, <1> ... <16>, <Enter> (<Space> or <Left Shift> + <Enter>)	Switch to a source (computer, CPU) stored in the favorite list with a KVM connection (Video Only or Private Access connection).
<Hot Key>, <F1> ... <F16>	Execute a predefined macro (1-16).
<Hot Key>, <Left Shift> + <F1> ... <F16>	Execute a predefined macro (17-32).
<Hot Key>, <Num 0>	Switch USB-HID signal to own screen (CON Unit with keyboard and mouse).
<Hot Key>, <Num 1> ... <Num 4>	Switch USB-HID signal to screen #1 ... #4.