

<Hot Key>, <v>	Enter Command Mode (default)
<Left Shift> + <Esc>	Exit Command Mode
<Hot Key>, <v>, <a>	Configure video settings automatically (only with VGA/RGB/EGA input)
<Hot Key>, <v>, <1> ... <8>, <Enter>	Switch to port 1 ... 8



<Hot Key>, <v>, <Enter>	Open OSD
<Esc>	Exit OSD
<Cursor down>	Navigation down in the menu
<Cursor up>	Navigation up in the menu
<Enter>	Menu selection
<Backspace>	Leave sub menu
<Cursor right> or <Cursor left>	Change of settings in sub menus or selection of parameter values

<Hot Key>, <v>	Enter Command Mode (default)
<Left Shift> + <Esc>	Exit Command Mode
<Hot Key>, <v>, <a>	Configure video settings automatically (only with VGA/RGB/EGA input)
<Hot Key>, <v>, <r>	Reset to factory settings
<Hot Key>, <v>, <F1>, <Enter>	Direct selection input VGA
<Hot Key>, <v>, <F2>, <Enter>	Direct selection input DVI



<Hot Key>, <v>, <F3>, <Enter>	Direct selection input SDI
<Hot Key>, <v>, <F4>, <Enter>	Direct selection input Y/C (S-Video)
<Hot Key>, <v>, <F5>, <Enter>	Direct selection input YPbPr (Component Video)
<Hot Key>, <v>, <F6>, <Enter>	Direct selection input RGB
<Hot Key>, <v>, <F7>, <Enter>	Direct selection input EGA
<Hot Key>, <v>, <F8>, <Enter>	Direct selection input FBAS 1
<Hot Key>, <v>, <F9>, <Enter>	Direct selection input FBAS 2
<Hot Key>, <v>, <F10>, <Enter>	Direct selection input FBAS 3